

## **CHANGING 1060 CASH DRAWER LOCKS**

If you are changing the lock in a 1060 cash drawer, you would need to open the cash drawer and pop off the metal plate behind the lock with a screw driver. You do this by inserting the screw driver into the space behind the push button down as far as you can and slide screw driver towards the back of the cash drawer until the metal plate slides out. Once the back of the lock is exposed you should be able to unscrew 2 small screws and release the lock. Replace the lock in the same way.

If this does not assist you please give us a call back and we will try to help you through it.

Thanks,  
MMF Customer Service